



Growduino user manual

Version: Growduino V_2.0-OrPI purchased from 1.9.2018 until now.

Thank you for purchasing the Growduino. To achieve full satisfaction with this product please follow this user manual as follows.

Connection	2
Information about sensors arrangement	2
Light1 - Outdoor	2
Light2 - Indoor	2
DHT22 - Temperature1 a Humidity.....	2
Temp2 - Water temperature	2
Temp3 - Bulb.....	3
Usnd - Ultrasound distance	3
EC - electric conductivity	3
pH - Acidity/Alkalinity	3
CO2 - Carbon dioxide	3
Activation	4
Deactivation	4
How Growduino works.....	5
Measuring and recording of data	5
Display	5
Webserver-client	5
Sensors	6
Graphs	6
Relay state history	6
Outputs	7
Light	7
Fan - Ventilation	8
Humidifier	9
Watering/Irrigation.....	9
Refill.....	10
Heating	10
Water Heating	11
Dehumidifier.....	11
CO2 Dispenser	11
FreeTimer	12
Alerts	13
How do Alerts work	13
List of Alerts	14
Settings.....	15
Calibration.....	16
EC calibration.....	16
pH calibration	16
CO2 calibration	17
Maintenance	18
Username and password change	18
Troubleshooting	19
Further information.....	20
Scale, resolution and accuracy of sensors	20
Resistance.....	20
Electric safety	21

Connection

Do not plug in the device into the mains right after you unwrap it. Do not switch it on. Follow further steps as shown in this manual.

In the space selected, install all required sensors into ports as labelled on Growduino. When you hear a click for the connector from both the sensor and Growduino the connection was performed correctly. There is no need for using force, it should allow you to connect it easily. Sensors are not waterproof (except the temperature sensor for irrigation), do not place these near running water, including rain. Use only full copper cables for sensors. When using other than supplied cables, proper functionality can not be guaranteed.

Information about sensors arrangement

Light1 - Outdoor

Sensor for measuring amount of light outside the cultivating area. It is used for managing light inside a box/greenhouse, see Output Light. Make sure that direct sun light falls on the box when placing - the grey/brown disc should face towards the sky. Artificial light must not fall onto the sensor, it would distort measured values. At the same time, however it must not be exposed to rain and running water. Ideal placement is inside a greenhouse, preferably on the ceiling.

Light2 - Indoor

Sensor for measuring amount of artificial light produced. It is used for managing light function; see Alert " When Lighting Indoor is... ". Place the box in the close proximity to the lighting with the disk directed towards the source of light. If you use lighting that generates substantial amount of heat (such as vacuum tubes MH or HPS, infra, but also very strong LED or CFL), place the plastic box in sufficient distance to prevent any melting. To check if the distance is ideal, hold your hand there for 5 minutes with no result of burns :-)

DHT22 - Temperature1 a Humidity

Sensor for measuring air temperature and relative humidity. It is used for managing ventilation, see Output Fan. Provided that you use artificial lighting, place it levelled with the tops of the plants. If you do not use artificial lighting, place it between second half and top third of the selected space. Make sure it is not installed in direct light, near any source of heat (light) or amongst dense vegetation; it may cause distorted measurement.

Temp2 - Water temperature

Waterproof sensor for measuring water with fertilizers temperature or water in aquaponic system. It also allows measurement of air temperature, as such you can use it to control temperature of grow space. It manages cooling of aquaponic medium by increasing level of cold water, see Output Refill, or sending information with respect of warm or cold water via mail, see Alert "when Water Temperature is...". Place the sensor where you aim to measure the water temperature. The waterproof part of the sensor starts at the metal tube up to the connection outset into the flat cable.

Temp3 - Bulb

Sensor for measuring air temperature at the lighting, it is used as a thermostat for protection, see Output Light. Place the sensor to such distance from the lighting, until it displays temperature of approximately 50-60°C after heating up. If you use lighting that generates substantial amount of heat (such as vacuum tubes MH or HPS, infra, but also very strong LED or CFL), place the plastic box in sufficient distance to prevent any melting. To check if the distance is ideal, hold your hand therefor 5 minutes with no result of burns :-)

Usnd - Ultrasound distance

Sensor that uses ultrasound to measure distance. It is used for increasing water level control, see Output Refill, but also for notifications of low or excess of water, see Alert "When sensor distance...". Place the sensor on the lid of the water container or above the aquaponic tank at such position so that the cylinder emitter/receiver aims perpendicularly to the water surface.

EC - electric conductivity

Sensor for measuring electric conductivity in liquids. Shows amount of dissolved nutrients. Used for send notifications of low or excess EC. Sensor probe is connected to converter using BNC connector. The converter is not water resistant. Sink the sensor 2-4 cm under water surface. When ordered together with pH sensor, 3D printed floater will be included for free. If necessary, clean the probe gently by ultrasoft toothbrush. This sensor is factory calibrated for use with included cable length. See chapter Calibration.

pH - Acidity/Alkalinity

Sensor for measuring acidity in liquids. Based on measured values You will receive email alert when pH is too high or low. Sensor probe is connected to converter using BNC connector. The converter is not water resistant. Sink the sensor 2-4 cm under water surface. When ordered together with EC sensor, 3D printed floater will be included for free. If necessary, rinse the probe gently a stream of water. This sensor is factory calibrated for use with included cable length. See chapter Calibration.

CO2 - Carbon dioxide

Sensor for measuring amount of CO2 in air. Based on measured values You can drive electronic valve and dispense CO2 into your grow area. Of course You will receive email alert when CO2 is too high or low.

The resolution is 1 PPM, range 0-40000 PPM. For the most effective measurement, place the sensor freely in the room, away from the valve mouth, other sensors or lighting. The sensor will heat up for about 30 minutes after switching on, and the wrong location would distort other sensor measurements and also CO2 measurements.

This sensor is factory calibrated for the purchased unit and the cable length used. See chapter Calibration.

Activation

1. To prevent any electrical hazards and due to assumed high humidity, place the central Growduino unit away from the cultivating area.
2. Plug the ethernet cable into the last port on Growduino marked ETH. The other end of the cable is to be plugged into your router/switch. This will allow you to connect to your home LAN network. On the side of Growduino, there is MAC address for DHCP server. IP address is provided separately in accessories. IP can be changed on the configuration page at a later date.
3. If for some reason the Growduino IP address does not correspond with address range of your LAN, it is necessary to set the range up on your PC/notebook. Then you may change the IP as required in the Growduino web configuration. For further information, please, contact your IT specialist.
4. Plug 230V cable in and switch Growduino on. Display will light up, a text SETUP DONE, CONNECTED will appear. As soon as the red LED control light indicating sensors reading dies out, Growduino is ready for use. Then last measured values appear on the display. To wait 5 minutes for stabilize sensor reading (30 minutes for CO20 is recommended).
5. Try if Growduino is responding to command ping: run command line, you usually find it in menu Start->Programs->Accessories->Command Prompt . Type "ping 192.168.1.1xx" (without inverted commas) where xx replace according to your Growduino IP. You should receive 4 responses. Should you not receive all 4 responses or you should not receive a response on all 4 pings "Your time limit expired", return back to the last sentence of point 3.
6. Supported browser is Google Chrome. Input IP address of your Growduino in the browser, such as 192.168.1.1xx. Once the application is uploaded (it can take a few seconds), you should then see a page with graphs according to the current values of the sensors read from the memory. If you need to adjust the setting, continue via "Settings".

Deactivation

1. Always turn off Growduino only when red diode signaling sensor reading do not lit. If You try to turn off Growduino during measure and write cycle, data can be corrupted and Growduino may not work properly after that.
2. Switch Growduino off with switch on the side, near 240V power cable.
3. If your Growduino is equipped with internal UPS, push the "UPS OFF" button for about 15 seconds until display goes out to switch off completely.
- 4.

How Growduino works

Measuring and recording of data

Growduino, is above sensors and relay with outlet sockets also equipped with a control microcomputer. In regular minute intervals, this microcomputer recalculates measured data by the sensors and saves them into internal database. It simultaneously, evaluates user settings and switches output sockets ON or OFF accordingly. Every measurement, saving and evaluating of data lasts about 10-20 seconds. During this period of time Growduino is not accessible from the network, that can cause longer waiting for data to display. However the LED control light on Growduino is either on or is flashing whilst in process of measuring or saving.

Warning – when the LED control light is on and a cycle of measuring and saving data, do not switch off or reset Growduino, you would damage data.

Display

Selection of information which may appear on the display:

Air Temp – temperature of air from sensor DHT22

Humidity – relative air humidity from sensor DHT22

Water Temp – temperature from sensor Temp2 (waterproof)

Water level – distance in cm from water surface to sensor USND

Etc...

At a start up, various information about the system Growduino appear, such as initialisation and completion of the start up cycle ("DONE.").

Webserver-client

There also runs a program on the micro computer of Growduino, it responds to network requests, so called Webserver. When you type your Growduino IP address your browser address bar, webserver responds, sends it to your PC page (client, client application). During loading, the display shows "Loading application...". This application will run in the browser and requests measured data from Growduino whilst displaying "Loading backend status...". Once all the data are uploaded by the browser, it is displayed as a web page. Page Sensors displays first.

The left bar is used for switching between pages:

Sensors – default page with graphs and information of connected outputs

Outputs – page for output settings according to measured values

Alerts – page for alert settings to emails

Settings – Growduino system settings, see introduction

Calibration – some of sensors calibration

Maintenance – backup, delete, upload

Warning – the application has got the same layout regardless what sensors and outputs you purchased. Please ignore any graphs or outputs, which are not connected.

Sensors

Page “Sensors” is the primary page showing measured values of sensors.

Graphs

It is possible to zoom certain parts in graphs, either with a mouse or a finger on touch devices. The time graph shows data measured every minute – how the measuring cycles run. Daily graph displays hourly averages, monthly graph displays daily averages.

Thus, it is possible to display various periods by clicking on Month, Day, Hour Calendar and arrows left and right. A button with a pictogram of a house returns you back to the current data. It is however dependent on previously selected calendar Month, Day or Hour. That means, when you press DAY and select a certain day in past and then you click on the house, the current day will display. When you press HOUR and select a certain hour in past and then you click on the house, the current hour will display. Calendar responses equally – it depends if you wish to select hours, days or whole months. On the right from the arrows you see date and time of displayed data.

Relay state history

In the left column, under page switches, there are individual output devices displayed. If they are grey, output is switched off. Green means output is switched on. Relay state history is displayed underneath them – entries referring to connected outputs.

As well as at graphs, you can browse relay state history. Depending on the internet or LAN connection speed and number of relay changes during the day it can take a few seconds to display selected hour/day. Relays history is not working in month browsing mode.

Outputs

This page is used for setting up output devices:

Under each output, there are buttons for manual switch on and off or over to automatic control according to setting.

Warning – total load of all outputs at one time must not exceed 10A, that is for 230V max 2300W.

Important - when setting time range, the day starts at 00:00 and ends at 24:00.

Examples:

When You need to shine a light from midnight to six AM, set 00:00-06:00.

When You need to shine a light from 8PM to midnight, set 20:00-24:00.

When You need to shine a light from 10PM to 10AM (through night), set 22:00-10:00.

Light

Intelligent light control

Growduino allows switching lights on according to light volume outdoors, it is suitable for example when adding light in a greenhouse out of season or early in the morning or evening. To allow this, purchase of Light sensor 1 Outdoor is necessary.

Press tick symbol in the circle, it changes to "no stopping" and conditions for switching fields will activate. Condition is: Switch on, at time from xx:xx to xx:xx and light outside is less than xx, leave switched on until light outside increases above xx.

Example – we know, that sunrise starts approx. at 4am, however it does not shine with full intensity onto the green house until 9am. Until then Light Outdoor in the graph shows maximum of 60. In the evening the sun sets already at 7pm, however we need the light on the plants till 10pm. Settings would be then: Switch on, when time is from 04:00 to 22:00 and light outside less than 50, leave switched on until light intensity increases to 60. Then click Save on the bottom of the page. As soon as the settings are saved, "Save successful" appears on the display. For cancellation click on the "no parking" sign and save.

Note: values 50 and 60 from the example above adjust to your own conditions directly at the location. Their extent also determines hysteresis required to prevent lighting switching on and off too often, such as cloud movement on the sky. Light will turn off automatically whenever light outdoors exceeds set value or after set time period will come to an end.

Lighting thermostat

Once the function is active, light does not switch on until temperature from sensor Temp3 falls under set temperature. Press tick symbol in the circle, it changes to "no stopping" and conditions for switching fields will activate. Set required temperature above which the lighting must not switch on. Then click Save on the bottom of the page. As soon as the settings are saved, "Save successful" appears on the display. For cancellation click on the "no parking" sign and save.

Note: You may place the sensor on tips of the plant leaves to prevent any switching light on unless there is too warm in that area thus protecting plants from overheat or burn (caused by ventilator damage, no further heat from lights will be generated into the space).

Standard timer

You can set up standard digital timer with assistance of +add interval. Press +add interval, input time from and to. Then click Save on the bottom of the page. As soon as the settings are saved, "Save successful" appears on the display. You can set up several intervals, if required. For cancellation press cross sign and save.

Fan - Ventilation

Thermostat preventing too much intake of cold air

Growduino does not permit switching the ventilation on if the temperature in the silvicultural space (Air Temperature) is too low. It can protect the plant in case a window is left opened which would otherwise allow a dangerously cold air being sucked into the silvicultural space.

Condition is: Never turn on the ventilation if the temperature is below $xx^{\circ}\text{C}$.

Press tick symbol in the circle, it changes to "no stopping" and conditions for switching fields will activate. Set the desired temperature below which the ventilation can not be switched on. Then, at the bottom of the page, press Save. Once the settings are saved, the message "Save successful" will display. To cancel, press "no stopping" and then save.

Maintaining the desired temperature

Growduino allows to maintain the temperature range in the silvicultural area through ventilation. You can set different conditions for day and night mode.

Condition is: Switch the ventilation on at time from $xx:xx$ to $xx:xx$ and when the temperature exceeds $xx^{\circ}\text{C}$ and ventilate until it falls below $xx^{\circ}\text{C}$ or the time runs out.

Press tick symbol in the circle, it changes to "no stopping" and conditions for switching fields will activate. Set the desired temperature range to be maintained. Range is important because of hysteresis for the ventilation not to switch on and off too often. Then, at the bottom of the page, press Save. Once the settings are saved, the message "Save successful" will display. To cancel, press "no stopping" and then save.

Maintaining the required humidity

Growduino allows to maintain the humidity range in the silvicultural area through ventilation. You can set different conditions for day and night mode.

Condition is: Switch the ventilation on at time from $xx:xx$ to $xx:xx$ and when humidity exceeds $xx\%$ and ventilate until it falls below the $xx\%$ or the time runs out.

Press tick symbol in the circle, it changes to "no stopping" and conditions for switching fields will activate. Set the desired humidity range to be maintained. Range is important because of hysteresis for the ventilation not to switch on and off too often. Then, at the bottom of the page, press Save. Once the settings are saved, the message "Save successful" will display. To cancel, press "no stopping" and then save.

Maintaining max CO₂ concentration

Growduino allows to maintain maximum CO concentration in the silvicultural area through ventilation. You can set different conditions for day and night mode.

Condition is: Switch the ventilation on at time from $xx:xx$ to $xx:xx$ and when CO₂ exceeds $xxx\text{PPM}$ and ventilate until it falls below the $xxx\text{PPM}$ or the time runs out.

Press tick symbol in the circle, it changes to "no stopping" and conditions for switching fields will activate. Set the desired CO₂ range to be maintained. Range is important because of hysteresis for the ventilation not to switch on and off too often. Then, at the bottom of the page, press Save. Once the settings are saved, the message "Save successful" will display. To cancel, press "no stopping" and then save.

Intelligent timer

Growduino, in addition to temperature and humidity control allows periodic switching on of the output FAN - Ventilation. It is important when both temperature and humidity are within the specified limits but you still wish to ventilate the enclosed silvicultural room and increase e.g. air quality inside. You can set different conditions for day and night mode.

Condition is: At time from $xx:xx$ to $xx:xx$ switch on every xx minutes and leave running for xx minutes or until the time runs out.

Press the tick symbol in the circle, it changes to "no stopping" and conditions for switching fields will

activate. Set the desired interval and switching time. Then, at the bottom of the page, press Save. Once the settings are saved, the message "Save successful" will display. To cancel, press "no stopping" and then save.

Example: I want the entire space to be ventilated every 15 minutes. I know my ventilator can handle 250 m³/hour, which is, according to the conversion, approximately 4m³/minute. The size of the space is 2x1x2m, i.e. 4 m³ - 1 minute should therefore suffice for a complete air exchange. I set Growduino's intelligent timer for: every 15 minutes ventilate for 1 minute.

Note: always enter only whole minutes in the first field. For example, if you need to time it for 2 hours, enter 120 (2x60).

Standard timer

You can set the standard digital timer by + add interval. Press + add interval, enter the time from and time to. Then, at the bottom of the page, press Save. Once the settings are saved, the message "Save successful" will display. There can be more intervals set if needed. To cancel press the hashtag and then save.

Humidifier

Growduino lets you increase the humidity in the silvicultural area as per settings.

Condition is: Switch output for humidifier on, when humidity drops below xx% and humidify until it reaches xx%. Press the tick symbol in the circle, it changes to "no stopping" and conditions for switching fields will activate. Set the desired humidity range to be maintained. Range is important because of hysteresis so the humidification didn't switch on and off too often. Then, at the bottom of the page, press Save. Once the settings are saved, the message "Save successful" will display. To cancel, press "no stopping" and then save.

Intelligent timer

Growduino allows periodic switching on of the output Humidifier.

Condition is: Switch on every xx minutes and leave running for xx minutes.

Press the tick symbol in the circle, it changes to "no stopping" and conditions for switching fields will activate. Set the desired interval and switching time. Then, at the bottom of the page, press Save.

Once the settings are saved, the message "Save successful" will display. To cancel, press "no stopping" and then save.

Standard timer

This output has a standard timer as well, it is set in the same way as FAN - ventilation.

Watering/Irrigation

Irrigation is switched on using an intelligent or standard timer.

Pump fuse

It is possible to set the fuse against depletion of the water in the tank so that the pump does not run without water.

The condition is: Never switch on irrigation if the water surface distance from the USND sensor is more than xx cm.

Press the tick symbol on the wheel, change to stand-by, and the field for switching conditions are activated. Set the desired maximum distance. Then click on the bottom of the page to save. Once the settings are saved, the message "Save successful" is displayed. To cancel, press the ban to stay and then save.

Intelligent timer

This output has an intelligent timer as well, it is set up in the same way as HUMIDIFIER.

Example: I wish to irrigate 6 times a day and I know that thanks to the power of the pump and piping diameters of the tubes 2 minutes will be enough for it to be sufficiently watered. So I set the timer to run every 240 minutes (24 hours / 6 = every 4 hours, i.e. every 240 minutes), and irrigate for 2 minutes. Then, at the bottom of the page, press Save. Once the settings are saved, the message "Save successful" will display. To cancel, press "no stopping" and then save.

Standard timer

This output has a standard timer as well, it is set in the same way as FAN - ventilation.

Refill

Growduino allows refilling the water tank based on measuring the distance of the sensor from the water surface by a pump or a solenoid valve. It is also possible to add cold water into the aquaponic system if the fish tank is too hot in the summer months.

NB: If you want to use refilling with conditions, it is necessary to purchase USND sensor (ultrasonic distance measurement) or Temperature sensor 2 - waterproof temperature sensor.

Condition 1: Start refilling when the water surface is from the sensor more than xx cm and stop refilling when it is reduced to xx cm (water surface is rising closer to sensor).

Condition 2: Start refilling when the water temperature is higher than xx ° C and stop when it falls to xx ° C.

Press the tick symbol in the circle, it changes to "no stopping" and conditions for switching fields will activate. Set the desired distance range for the water surface to be maintained. Range is important because of hysteresis so the refilling didn't switch on and off too often, for example due to water ripples. Or, set the temperature you want to maintain. Then, at the bottom of the page, press Save. Once the settings are saved, the message "Save successful" will display. To cancel, press "no stopping" and then save.

NB: There is no need to set both conditions, set which you want to use. In case of refilling the water because of temperature, it's better to have an overflow drain.

Intelligent timer

This output has an intelligent timer as well, it is set in the same way as HUMIDIFIER.

Standard timer

This output has a standard timer as well, it is set in the same way as FAN - ventilation.

Heating

Growduino allows heating of the silvicultural area on the basis of temperature measurement (sensor DHT22). This heating is particularly suitable for lower wattage, such as heating pads, but can be used for a smaller heater (when ordering ask for the heatsink for SSR relay, however, it must be specified that the overall wattage of Growduino must not exceed a total maximum of 2300W).

The condition is: Turn on the heating when the air temperature falls below xx ° C and heat until the temperature reaches xx ° C.

Press tick symbol in the circle, it changes to "no stopping" and conditions for switching fields will activate. Set the desired temperature range to be maintained. Then, at the bottom of the page, press Save. Once the settings are saved, the message "Save successful" will display. To cancel, press "no stopping" and then save.

Intelligent timer

This output has an intelligent timer as well, it is set in the same way as HUMIDIFIER.

Standard timer

This output has a standard timer as well, it is set in the same way as FAN - ventilation.

Water Heating

Growduino allows heating of water, fertilizer/nutrient solution or aquaponic tank on the basis of temperature measurement (sensor Temp2 - water). This heating is particularly suitable for lower wattage, such as aquarium heater. If power drain is 250W or more, ask for the heatsink for SSR relay when ordering. However, it must be specified that the overall wattage of Growduino must not exceed a total maximum of 2300W.

The condition is: Turn on the heating when the water temperature falls below xx ° C and heat until the temperature reaches xx ° C.

Press tick symbol in the circle, it changes to "no stopping" and conditions for switching fields will activate. Set the desired temperature range to be maintained. Then, at the bottom of the page, press Save. Once the settings are saved, the message "Save successful" will display. To cancel, press "no stopping" and then save.

Intelligent timer

This output has an intelligent timer as well, it is set in the same way as HUMIDIFIER.

Standard timer

This output has a standard timer as well, it is set in the same way as FAN - ventilation.

Dehumidifier

Growduino allows switching on dehumidifier based on the measurement of relative humidity using sensor DHT22.

NB: It is necessary to use such a dehumidifier which does not require microswitch button control to switch it on - one that simply requires plugging into the socket or rocker switch to be switched on, with manual control (AC-5488 Tristar, STEBA LE 100 Master DH 711). To drive a dehumidifier which does require microswitch button control to switch it on, contact technical support at Growduino web pages.

The condition is: Switch dehumidification on when the humidity is greater than XX% and dehumidify until it falls to xx%.

Press tick symbol in the circle, it changes to "no stopping" and conditions for switching fields will activate. Set the desired humidity range to be maintained. Range is important because of hysteresis for the dehumidifier not to switch on too often. Then, at the bottom of the page, press Save. Once the settings are saved, the message "Save successful" will display. To cancel, press "no stopping" and then save.

Intelligent timer

This output has an intelligent timer as well, it is set in the same way as HUMIDIFIER.

Standard timer

This output has a standard timer as well, it is set in the same way as FAN - ventilation.

CO2 Dispenser

Allows You to dose a CO2 gas using electromagnetic valve into silvicultural area. It's driven by CO2 sensor. Measuring cycle is one minute, use of a needle adjusted valve is recommended for fine dosing. Intelligent condition settings prevents to open the valve during ventilation running.

Condition 1 is: Never open the valve if the temperature is over xx °C.

Condition 2 is: Never open the valve if the humidity is over xx %.

Condition 3 is: Switch the valve on at time from xx:xx to xx:xx and when CO2 falls below xx ppm and leave open until it exceeds the xx ppm or the time runs out.

Intelligent timer

This output has an intelligent timer as well, it is set in the same way as HUMIDIFIER.

Standard timer

This output has a standard timer as well, it is set in the same way as FAN - ventilation.

FreeTimer

This output is useful, for example, for blowing on plants – wind simulation, lighting using special lamps, regular oxygenation of the filler/grout using air stones, mixing the water with nutrients in the water tank using a circulating pump ... the possibilities are open.

Intelligent timer

This output has an intelligent timer as well, it is set in the same way as HUMIDIFIER.

Example: I want to simulate wind every 20 minutes so it blows for the duration of 2 minutes. So I select to run every 20 minutes and leave on for 2 minutes. Then, at the bottom of the page, press Save.

Once the settings are saved, the message "Save successful" will display. To cancel, press "no stopping" and then save.

Standard timer

This output has a standard timer as well, it is set in the same way as FAN - ventilation.

Alerts

For the option of sending notices the Settings page is required to be filled in as follows:

SMTP server - Growduino can send emails only without the user being logged on, i.e. you need your server provider to allow you to send mails from inside of the network without the need to login. Enter the IP address of the server, not the DNS name. For more information, contact your Internet provider.
SMTP port - normally 25. For more information, contact your Internet provider.

System name - enter up to 8 characters.

E-mail from - enter the email address of the sender, this may be fictional but must have a valid format (something@something.something) and real existing domain. We recommend an existing/your second address to fill in, in such case of undeliverable alert it will be returned to this address.

How do Alerts work

After setting the conditions within the minute measuring and storing cycle, Growduino finds that the condition was met / exceeded and sends an e-mail with the text from the field "On message". Once the measured value in subsequent cycles drops below the set value, it sends an email with the text from field "Off message".

Condition: When the value exceeds xx, send an email to xx@xx.xx with the text xx. Once it falls below the set value in the first field, send an email with the text xx.

Example 1: I have a USND sensor for the distance from surface of water in water tank and I want to receive alerts when the water is running out. According to the size of the container I know that, for example, the 40cm distance of the surface from the sensor means that the water will run out soon. So I set up Alert "When sensor distance is over" 40cm, then my email and into the text fields I enter "Water running out!" and "Water level is OK again".

Saving and deactivating works in the same way as with the outputs control. Set the alerts one at a time.

Tip: Using the Alert for water level, you can also tell whether the pump hasn't used up all the water at once. If you know you filled up yesterday and as such it should not have been used up today, and Growduino reports that it has, it is time for spatial check.

Example 2: I have a sensor Light sensor 2 (indoor) located under the light and want to check whether the lighting works as it should. So I set the alert "When Indoor Lighting is below" ("When the amount of light is less than") to e.g. 70 and I set the time for the period when the light is supposed to be controlled according to the settings on the Outputs page. I fill in the texts for On message "Light is not on but should be!" and Off message "The light is on again." Likewise, you can fill in the opposite Alert "When Lighting Indoor is over" ("When the amount of light is greater than"), for example, set the value to 70, only in the time field I set the values for the light to switch off.

Tip: Using Alert "When Lighting Indoor is over", when the value setting is low, you can be notified via email if there is outside light penetrating the silvicultural area.

List of Alerts

When the air temperature rises above xx
When the air temperature falls below xx
When the water temperature rises above xx
When the water temperature drops below xx
When the humidity rises above xx
When the humidity falls below xx
When the distance between the sensor and the level rises above xx
When the distance between the sensor and the level drops below xx
When the light is not working when it should
When light is on when it should not
When pH rises above xx
When pH falls below xx
When EC rises above xx
When EC falls below xx
When CO2 rises above xx at a certain time
When CO2 falls below xx at a certain time
When battery capacity falls below xx
When there is a power outage

Settings

On the Settings page, you can manually fill in the fields for:

- a. DHCP checkbox - when checked, IP address, Netmask and Gateway address will be obtained automatically from DHCP server, typically a home router.
- b. HTTPS* checkbox - when checked, solely encrypted secure communication will be used and Growduino will require password logon. Default login name and password are "grdw", written without quotation marks.
- c. IP, Netmask and Gateway - can be manually filled and will work only if DHCP checkbox is not checked.
- d. NTP server - where Growduino compares the exact time of the Internet.
- e. Time zone - in which time zone you are in. Allows to set summer or winter time, if present.
- f. SMTP server and port for sending email Alerts (see Alerts). It must be the SMTP server through which you can send mail without authentication of the username and password, your provider's internal SMTP server usually allows this.
- g. System name – what is your Growduino called (this name is written into email Alerts).
- h. E-mail from - who is the sender of the email, SMTP servers require some. You can enter an actual existing address or e.g. test@test.com. Some providers check the domain if exists. Using actual real existing email address is recommended.

Please pay attention to accuracy for entered data. Entering incorrect data can lead to unavailability of Growduino on the network or malfunction of certain functionalities. Click on Save, the settings are saved. The settings will take effect after minute or two, Growduino will reset itself automatically.

Reset to default settings

Push the blue button RESET located on the side of Growduino and hold it for 15 seconds, then release. Default settings will work afret minute or two, Growduino will reset itself automatically. After reset there is DHCP checked, HTTPS unchecked and login name and password se to "grdw", written without quotation marks.

* HTTPS

For technical reasons, secure communication on a device with a changeable IP address is solved using the so-called Self Signed Certificate. These certificates are not authenticated by an external Certification Authority, so the browser can evaluate them as untrusted/unsecured. This authentication has no effect on the functionality of encrypted communications. To continue working with Growduino, confirm in the browser that you want to enter the page despite the warning.

Calibration

Sensors shipped together with basic unit are factory calibrated. As soon as cable length, power source or sensor is changed, recalibration is needed. We also suggest recalibrate once per month to achieve best accuracy.

EC calibration

EC calibration is two point with offset. It is done using calibration solutions with value EC 1,278 and EC 4,523 at a liquid temperature of 20°C.

Solution EC 1,278 , Hanna code HI7031L

<http://hannainst.com/hi7031l.html>

Solution EC 4,523 , Hanna code HI7039L

<http://hannainst.com/hi7039l.html>

Procedure:

1. Both solutions need to have temperature of 20°C
2. Sink the probe into EC 1,278 solution for about 2-4cm under surface. Please ensure it do not contact sides or bottom of container. On the Calibration page click corresponding "Get raw data" button. Repeat this measure until it's stable enough. Then click Save.
3. Repeat this procedure for EC 4,523 solution.
4. Sink the probe into clear water, let a few measure cycles run, look at the values in graphs on the Sensors page. Value of clear water should be 0,3-0,4 EC. If not, set an offset on calibration page, try 1 or -1 and let measure cycle run again. Depending on result, set offset value higher or lower until desired value 0,3-0,4 EC is measured.
5. Now the sensor is calibrated and control measurement of all solutions should be OK.

pH calibration

pH calibration is two point. It is done using calibration solutions with value pH 4,00 and pH 7,03 at a liquid temperature of 20°C.

Solution pH 4,00 , Hanna code HI7004L

<http://hannainst.com/hi7004l.html>

Solution pH 7,03 , Hanna code HI7007L

<http://hannainst.com/hi7007l.html>

Procedure:

1. Both solutions need to have temperature of 20°C
2. Sink the probe into pH 4 solution for about 2-4cm under surface. Please ensure it do not contact sides or bottom of container. On the Calibration page click corresponding "Get raw data" button. Repeat this measure until it's stable enough. Then click Save.
3. Repeat this procedure for pH 7 solution.
4. Now the sensor is calibrated and control measurement of both solutions should be OK.

CO2 calibration

CO2 calibration is two point. Very high accuracy is not possible without laboratory equipment (CO2 and O2 chamber, gas chromatograph), so there is a procedure using statistically proven values.

Procedure:

1. Let the sensor heat up for 15 minutes after switch on.
2. Place the sensor into a well ventilated room. Ideally calibrate outside, out of urban area, open-air, in the shadow and no wind, temperature about 20°C. Environment like this has 400 PPM CO2 concentration.
3. On the Calibration page click corresponding "Get raw data" button. Repeat this measure until it's stable enough. Then click Save.
4. Place the sensor into a small closed area, like plastic bag. Fill the bag with CO2 gas (for example from a carbonated beverage maker). Or You can breathe into a bag - perform as many breaths and puffs until You feel dizzy. This is a sign of high CO2 and low oxygen concentration. Seal the bag and click corresponding "Get raw data" button now for CO2 PPM 40K. Then click Save.
5. Now the sensor is calibrated and should measure about 400 PPM on fresh air. The value may vary depending on wind, movement of persons, environment, breathing persons close to sensor, etc - it is very sensitive.

Maintenance

On the Maintenance page you can backup, upload or delete the settings and configuration.

Backup settings - backup or upload values from Settings page.

Backup calibration - backup or upload values from Calibration page.

Backup Outputs&Alerts - backup or upload values from Outputs and Alerts pages together.

Delete Outputs&Alerts - delete all the values from Outputs and Alerts pages together.

Change password - redirects user to a form for username and password change

Username and password change

On the maintenance page, use the "Change password" button to go to the form to change your username and password. We strongly recommend that you enter this form only in HTTPS encrypted communication mode, see the Settings chapter.

1. For any change, it is always necessary to fill in the existing password name. The default setting is the name and password "grdw", written without quotation marks.
2. To change your username, enter the new name in the "New username" field.
3. To change your password, enter a new password in the "New password" and "Retype password", both fields must match. The password must not contain a colon at any place and space at the beginning or at the end.
4. It is possible to change the name and password at the same time, but it is not required by the system.
5. After pressing "Submit" wait 1-2 minutes, Growduino will restart. Restart is completed when "Connected" appears on the display.

Troubleshooting

1. If "Starting done ..." appears on the display after the start of Growduino for more than two minutes and "Connected" does not appear, press the 2x shortly the blue RESET button on the side of Growduino. The device restarts and should work properly.
2. If your browser does not load the whole page but only its part or if a saved setting is missing which you know it exists, delete cache of your browser. Then reload the page and it should be complete.
3. If you know that you have saved an incorrect setting on the OUTPUTS or ALERTS page and it can not be repaired via the browser or restart, contact support@growduino.cz for technical support.
4. If you know that you have saved an incorrect setting on the SETTINGS page, Growduino is not available on the network and it is not possible to fix it through the browser or by restart, reset the Growduino to default settings. See the Settings chapter for the procedure.
5. If You get wrong or not any time on the right side of arrow buttons on the Sensors page, and / or graphs are not loading during browsing through history and Relays History shows wrong time, your Growduino is probably not connected to internet or NTP server entered at Settings page is not available. Growduino will set time automatically if correct values on the SETTINGS page are entered (NTP server, Gateway, etc.) and internet connection is available. There is no possibility to set the time manually right now

Further information

Scale, resolution and accuracy of sensors

Name	Scale	Resolution	Accuracy
Light	0-100 units	0,1 unit	1 unit
DHT22	-40°C - +80°C / 0-100% RH	0,1°C / 0,1% RH	+0,5°C / +-2% RH
Temp Water	-10°C - +85°C	0,1°C	+0,5°C
Temp Bulb	-10°C - +85°C	0,1°C	+0,5°C
USND	6-200 cm	1cm	1cm
EC	0,3-8 EC	0,01 EC	0,1 EC
pH	0-14 pH	0,01 pH	0,1 pH
CO2	0-32000 PPM	10 PPM	10 PPM

Resistance

Název	Water/humidity	Temperature	Dust	Notes
Basic unit Growduino	0-50% RH	-10°C - +50°C	partially resistible	Water must not condense and run over connecting ports of sensors and ETH, temperature must not fall below condensation point , ports must not clog with dust .
Sensor Light	0-90% RH	-10°C - +80°C	partially resistible	Water must not condense, temperature must not fall below condensation point , ports must not clog with dust.
Sensor DHT22	0-90% RH	-10°C - +80°C	not resistible	Water must not condense, temperature must not fall below condensation point , ports must not clog with dust.
Sensor Temp Water	vodotěsné	-10°C - +85°C	resistible	Waterproof from the metal tube-up to beginning of the flat cable.
Sensor Temp Bulb	0-90% RH	-10°C - +85°C	partially resistible	Water must not condense, temperature must not fall below condensation point , ports must not clog with dust.
Sensor USND	0-90% RH	-10°C - +50°C	not resistible	Water must not condense, temperature must not fall below condensation point , ports must not clog with dust.
Sensor PH	0-90% RH	+1°C - +50°C	partially resistible	Water must not condense, temperature must not fall below condensation point , ports must not clog with dust. The probe is water resistant and must not freeze.
Sensor EC	0-90% RH	+1°C - +50°C	partially resistible	Water must not condense, temperature must not fall below condensation point , ports must not clog with dust. The probe is water resistant and must not freeze.
Sensor CO2	0-90% RH	-10°C - +50°C	not resistible	Water must not condense, temperature must not fall below condensation point , ports and sensor itself must not clog with dust.

Electric safety

Growduino was made according to correct technical practice from the standpoint of safety principles valid in European associations and if correctly installed, maintained and used to purpose for which it was produced, it should not put any person, pet, farm animal or property in danger. Growduino has not yet been tested by a certified authority and it is not as yet marked with CE Conformity Declaration. When it is required to open the basic unit of Growduino, it is important to first switch the device off, and disconnect from the mains. If Growduino is supplied via external UPS, it is important to disconnect it from the UPS also before the main unit is open.